

Connecting with RootBarrier® Connector

- If necessary, connect the connectors to each other to obtain the desired length by pressing the ends together until it clicks
- Slide the ends of HDPE into the connector and screw them tight